


Process Intensification Using Ionic Liquids as Solvents



Maaike C. Kroon

Delft University of Technology, The Netherlands




What are ionic liquids?

- Molten salts (consisting of cations and anions)
- Liquid at room temperature

Common cations:



Ammonium




Imidazolium




Pyrrolidinium



Pyridinium



Phosphonium



Guanidinium

Common anions:

- Halides: Cl⁻, Br⁻, I⁻
- Sulfates: CH₃OSO₃⁻
- Sulfonates: CF₃SO₃⁻
- Phosphates: PF₆⁻
- Borates: BF₄⁻
- Imides: N(CF₃SO₂)₂⁻
- Cyanates: N(CN)₂⁻
- Acetates: CF₃CO₂⁻

P. Wasserscheid, T. Welton, *Ionic Liquids in Synthesis*, Wiley-VCH Verlag: Weinheim, 2003.



What are ionic liquids?

- Negligible vapor pressure:
 - Non-volatile, non-flammable, odorless
 - No emission into the atmosphere
 - No solvent contamination in product
- Wide liquid temperature range
 - Tremendous kinetic control in reactions
- Good solubility characteristics
 - Suitable for multiphase catalysis
- Designer solvents



How 'green' are ionic liquids?

- Environmentally benign replacements for volatile organic solvents



However:

- The synthesis of some ionic liquids is not 'green'
- Some ionic liquids are toxic, non-biodegradable, and have low hydrolysis stability

→ Design a 'green' ionic liquid that has the ability to make a chemical process more environmentally benign!




How to intensify processes using ionic liquids?

- Simultaneous reaction and separation by the formation of a second product phase
- Simultaneous reaction and extraction using the miscibility switch phenomenon
- Simultaneous reaction and liquid membrane separation
- Simultaneous reaction and separation using ionic liquids as water-free electrolytes



Simultaneous reaction and separation by formation of a second product phase




Examples:

- Difasol process in ionic liquids
- Fischer-Tropsch process in ionic liquids




Conventional Fischer-Tropsch Process

- Wide product range
- Complex separation
- Mass transfer limitation at gas/solid interface



Novel Fischer-Tropsch Process

- Selective production of desired product (diesel), because longer alkanes are no longer soluble in ionic liquid
- No complex separation → low energy input
- No mass transfer limitation problems (catalyst and CO/H₂ are dissolved in ionic liquid phase)




Simultaneous reaction and extraction using the miscibility switch phenomenon



- Miscibility switch phenomenon: Carbon dioxide is able to force 2 immiscible phases into 1 homogeneous phase at pressure increase^{1,2}

¹C. J. Peters, K. Gauter, *Chem. Rev.* **1999**, *99*, 419.

²K. Gauter, C. J. Peters, A. L. Scheidgen, G. M. Schneider, *Fluid Phase Equilib.* **2000**, *171*, 127.




Miscibility windows phenomenon




¹M. C. Kroon, A. Shariati, L. J. Florusse, C. J. Peters, J. van Spronsen, G. J. Witkamp, R. A. Sheldon, K. E. Gutkowsky, *WO 2006/088348A1* (2006).

²A. M. Scurto, S. N. V. K. Aki, J. F. Brennecke, *J. Am. Chem. Soc.* **2002**, *124*, 10276.


Miscibility windows principle




Miscibility windows principle




Miscibility windows principle




Miscibility windows principle



Miscibility windows principle



Combining reactions and separations using the miscibility switch phenomenon



High p_{CO_2} : one phase

Low p_{CO_2} : two phases




Combining reactions and separations using the miscibility switch phenomenon

- Reaction in homogeneous system:
 - High reaction rate
 - No co-solvent needed to lower viscosity or enhance solubility of reactants
 - Catalyzed atom-efficient reaction
- Separation in biphasic system:
 - High separation rate (instantaneous demixing)
 - No ionic liquid contamination of the product
 - Ionic liquid phase with catalyst can be easily reused



Novel process set-up




M. C. Kroon, A. Shariati, L. J. Florusse, C. J. Peters, J. van Spronsen, G. J. Witkamp, R. A. Sheldon, K. E. Gutkowski, WO 2006/088348A1 (2006).



Application of the novel process set-up to a model system


Model reaction:



M. C. Kroon, J. van Spronsen, C. J. Peters, R. A. Sheldon, G. J. Witkamp, *Green Chem.* **2006**, *8*, 246-249.



Application of the novel process to a model system



Operation conditions:



Reaction in homogeneous phase:

- 150 bar, 50 °C, $x_{\text{CO}_2} < 50\%$
- 100 % conversion, 99% selectivity
- no catalyst deactivation

Separation in biphasic system:

- 120 bar, 50 °C, $x_{\text{CO}_2} > 50\%$
- simple and instantaneous
- pure product
- no solvent or catalyst losses

M. C. Kroon, A. Shariati, M. Constantini, J. van Spronsen, G. J. Witkamp, R. A. Sheldon, C. J. Peters, *J. Chem. Eng. Data* **2005**, *50*, 173-176.



Application of the novel process to a model system




Comparison with the conventional process:

| | Conv. Process | Novel process |
|------------------|---------------------|------------------------------|
| Stable catalyst | no | yes |
| Catalyst make-up | 0.27 g/kg product | 0 g/kg product |
| Solvent losses | yes | no |
| Solvent make-up | 2.86 kg/kg product | 0 kg/kg product |
| Energy for | evaporating solvent | pressurizing CO ₂ |
| Energy needed | 17.2 MJ/kg product | 4.8 MJ/kg product |



Application of the novel process to a model system




Economical and environmental advantages:

Operational costs per kg product:

| | Conv. process | Novel process |
|------------------------|---------------|---------------|
| Catalyst make-up costs | € 5.50 | € 0 |
| Solvent make-up costs | € 0.63 | € 0 |
| Energy costs | € 0.48 | € 0.13 |



Simultaneous reaction and liquid membrane separation






Examples:

- Separation of CO₂ from CH₄
- Steam-reforming




Steam reforming in ionic liquid membrane reactor



Advantages of ionic liquid membranes over conventional membranes


- Stable → ionic liquid does not evaporate
- High dispersion of catalyst (dissolved in ionic liquid) without sintering problems
- Additional selectivity by ionic liquid



TU Delft

Simultaneous reaction and separation using ionic liquids as water-free electrolytes


Example: production of aluminum



TU Delft

Ionic liquids as water-free electrolytes

- Electrolysis can be carried out at room temperature (high temperatures no longer needed)
 - Lower energy input
 - Lower electrical resistance
 - Safer and easier to handle
- Ionic liquids have large electrochemical windows and high conductivities



TU Delft

Conclusions

- Ionic liquids are alternative 'green' solvents that can replace volatile organic solvents
- Use of ionic liquids as solvents can result in considerable process intensification (lower energy input, lower cost):
 - Formation of second product phase
 - Use of miscibility switch phenomenon
 - Ionic liquid membranes
 - Use as water-free electrolytes



TU Delft

Acknowledgements

THANK YOU!!!

Isabel Arends
 Bianca Breure
 Marco Constantini
 Paul Durville
 Ioannis Economou
 Louw Florusse
 Eirini Karakatsani
 Gerard Hofland

Michiel Jansen
 Adri Knol
 Eliane Kuhne
 Cor Peters
 Sona Raeissi
 Astrid Schilderman
 Ali Shariati
 Roger Sheldon

Cretien Simons
 Vincent Toussaint
 Michel Van Den Brink
 Anton Van Estrik
 Fred Van Rantwijk
 Jaap Van Spronsen
 Geert-Jan Witkamp

TU Delft